



Module

Name	Quectel UG96, Teltonika TM2500
Technology	3G(UMTS/HSPA)/2G(GSM/GPRS)/GNSS/BLUETOOTH

GNSS

GNSS	GPS, GLONASS, GALILEO, BEIDOU, QZSS
Protocol compatible	NMEA, GGA, GGL, GSA, GSV, RMC, VTG
Receiver	Tracking: 33/99 acquisition channels
Tracking sensitivity	-165 dBm
Position Accuracy	< 2.5 CEP
Velocity accuracy	< 0.1m/s (within +/- 15% error)
Hot start	< 1 s
Warm start	< 25 s
Cold start	< 35 s

Cellular

Technology	UMTS/HSPA
2G bands	UG96: B5/B8/B3/B2
3G bands	UG96: B6/B5/B8/B2/B1
Data transfer	UG96: HSUPA: Max. 5.76Mbps UMTS: Max. 384Kbps (DL)/Max.384Kbps (UL) GPRS: Max. 107Kbps (DL)/Max.85.6Kbps (UL)
Data support	SMS (text/data)

Power

Input voltage range	10 - 30 V DC with overvoltage protection
Internal Back-up battery	170 mAh Li-Ion, 3.7 V battery (0.63 Wh)

Power Consumption

Ultra Deep Sleep	At 12V < 6mA
Deep Sleep	At 12V < 6.5mA
Online Deep Sleep	At 12V < 7mA
GPS Sleep	At 12V < 12mA
Nominal (with no load)	At 12V < 38mA

Bluetooth

Specification	4.0 + LE
Supported peripherals	Temperature and Humidity sensor, OBDII dongle, Inateck Barcode Scanner, Universal BLE sensors support

Physical specification

Dimensions	65 x 56.6 x 20.6 mm (L x W x H)
Weight	55 g

Operating environment

Operating temperature (without battery)	-40 °C to +85 °C
Storage temperature (without battery)	-40 °C to +85 °C
Operating humidity	5% to 95% non-condensing
Ingress Protection Rating	IP41
Battery charge temperature	0 °C to +45 °C
Battery discharge temperature	-20 °C to +60 °C
Battery storage temperature	-20 °C to +45 °C for 1 month -20 °C to +35 °C for 6 months

Interface

Digital Inputs	2
Digital Outputs	1
Analog Inputs	1
CAN Adapter Inputs	1
1-Wire	1
RS232	1
RS485	1
GNSS antenna	Internal High Gain
Cellular antenna	Internal High Gain
USB	2.0 Micro-USB
LED indication	2 status LED lights
SIM	2x SIM Card (Dual-SIM)
Memory	128MB internal flash memory

Features

Sensors	Accelerometer
Scenarios	Green Driving, Over Speeding detection, Jamming detection, GNSS Fuel Counter, DOUT Control Via Call, Excessive Idling detection, Immobilizer, iButton Read Notification, Unplug detection, Towing detection, Crash detection, Auto Geofence, Manual Geofence, Trip

Sleep modes GPS Sleep, Online Deep Sleep, Deep Sleep, Ultra Deep Sleep

Configuration and firmware update	FOTA Web, FOTA, Teltonika Configurator (USB, Bluetooth), FMBT mobile application (Configuration)
SMS	Configuration, Events, DOUT control, Debug
GPRS commands	Configuration, DOUT control, Debug
Time Synchronization	GNSS, NITZ, NTP
Fuel monitoring	LLS (Analog), Digital LLS (RS232, RS485), LV-CAN200, ALL-CAN300, CAN-CONTROL, OBDII dongle
Ignition detection	Digital Input 1, Accelerometer, External Power Voltage, Engine RPM (CAN Adapters, OBDII dongle)
RS232 Modes	Log Mode, NMEA, LLS, LCD, RFID HID/MF7, Garmin FMI, TCP ASCII/Binary, Magnetic card reader
RS485 Modes	Log Mode, NMEA, LLS, TCP ASCII/Binary

RS485 input voltage range on
A or B pin (common-mode
voltage) -7V to +12V

RS232 input voltage range
(common-mode voltage) +/-15V

RS232 input voltage range
(maximum operational
voltage) +/-25V

Certification & Approvals

Regulatory CE/RED (Quectel UG96), E-Mark (Quectel UG96), EAC, RoHS, REACH

